

Sub amp in W10.16 and W12.16

Problem: The blue light blinks and the relay clicks, and the amp cannot start.

Solution: Add a capacitor 470uF, 25V in parallel with C23 and C25





